

Test and Treat Drinking Water Safety System

Model - NEX-ABG 9TT

Problem

Drinking water sources are vulnerable to accidental or knowing contamination by individuals, groups, industry, medical labs, terrorists, and from naturally occurring radioactive materials (NORM). As yet very few water districts have real-time radiation monitors in place to protect the water and the public.

Solution

- For the first time in a **Continuous Real Time** monitor the **Nex-ABG-9TT series** solves this problem by continuously monitoring water using ultra-sensitive, radiation detectors.
- The information from these detectors is analyzed and displayed in units of picoCuries per liter.
- Monitors drinking water against most radioactive contaminants except H-3, C-14, S-35, Fe-55.

Nex-ABG-9TT

- The count times are user settable. Calculations are automatically updated every 2 minutes, every hour and every day. Measurements of radiation concentration are logged 24 hr/day, 7 day/week in. The longer update times correspond with greater precision and increased sensitivity.
- Sensitivities in the daily updates meet or exceed the DHS **PAG** (Protective Action Guideline Levels) for drinking water.
- The **Nex-ABG-9TT system is a Test and Treat system removing biological contaminations and reducing radioisotopes.**

Description

Model **NEX-ABG-9TT** is a radiation detection and treatment system for monitoring, measuring, and controlling Alpha, Beta and Gamma emitting radionuclides.. The electronics are microprocessor with LED/LCD display. The system is covered by TA's full one year warranty. On-site service contracts available in many areas.

The Alpha, Beta flow cell and Gamma detector are easily changed via disconnect fittings. All connections are sealed against leaks. The standard water moving system is based on a high precision pump. It has a 10 liter per minute capacity. System can also be operated using city water pressure in which case no pump is required.

A wide range of pump capacities are available to meet users' specific needs. The system detectors and electronics are ruggedly built. It comes complete with all cabling tubing and connectors in place and is ready to operate. 115 Volt 60Hz is standard; 220 Volt 50/60 Hz or battery operations are optional.

Detectors In This System:

1. **Alpha-Beta Detector** consists of a light-tight detector assembly which interfaces with the sample via quick disconnect coax cables and medical grade hoses. The sample is viewed by a matched pair of 5" diameter photo-multiplier tubes.
2. **Gamma Scintillation detector** has a sensitive 2" diameter crystal.
3. **BioSensor**
 - Oxidation Reduction Potential (ORP)
 - Total Organic Carbon (TOC)



TECHNICAL ASSOCIATES
OVERHOFF TECHNOLOGY

DIVISIONS OF
 US NUCLEAR CORP

7051 ETON AVENUE, CANOGA PARK, CA 91303 | 818-883-7043 | F: 818-883-6103
RGOLDSTEINTA@USNUCLEARCORP.COM | TECH-ASSOCIATES.COM | USNUCLEARCORP.COM